



DRC/DFM Check

DFM Summary (Bareboard):

Level: CRITICAL (7)

Minimum Annular Ring: Drill-Pad: 4 violation(s)
Minimum Clearance: Plane to Drill: 3 violation(s)

Level: ELEVATED (50)

Silkscreen over Soldermask: 25 violation(s)

Mask Slivers: 25 violation(s)

Level: MEDIUM (50)

Missing Mask Clearances: 25 violation(s)

Minimum Clearance: Mask (Pad to Pad): 25 violation(s)


DFM Error Report (Page: 2) Date: 08/18/2024@15:06:40

Minimum Annular Ring: Drill-Pad - (DFM Level: CRITICAL)

Ring Size = 4.8 (mils), Minimum allowed 5.0 (mils). This may make plating on vias, as well as solderability on component holes more difficult.

Location: 21.453, 13.520 (in.)

Layers: Art0121.pho, Drill.drl Attributes: NC Tool=4 Net=\$Net00173 Net=\$Net00173




Minimum Annular Ring: Drill-Pad - (DFM Level: CRITICAL)

Ring Size = 4.8 (mils), Minimum allowed 5.0 (mils) This may make plating on vias, as well as solderability on component holes more difficult.

Location: 21.259, 14.721 (in.) Layers: Art02.pho, Drill.drl

Attributes: NC Tool=2 Net=\$Net00059 Net=\$Net00059




Minimum Annular Ring: Drill-Pad - (DFM Level: CRITICAL)

Ring Size = 4.8 (mils), Minimum allowed 5.0 (mils). This may make plating on vias, as well as solderability on component holes more difficult.

Location: 21.175, 15.118 (in.)

Layers: Art0121.pho, Drill.drl Attributes: NC Tool=8 Net=\$Net00026 Net=\$Net00026




Minimum Annular Ring: Drill-Pad - (DFM Level: CRITICAL)

Ring Size = 4.8 (mils), Minimum allowed 5.0 (mils). This may make plating on vias, as well as solderability on component holes more difficult.

Location: 21.396, 15.971 (in.)

Layers: Art0121.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00008 Net=\$Net00008



Minimum Clearance: Plane to Drill - (DFM Level: CRITICAL)

Clearance = 4.8 (mils), Minimum allowed 7.0 (mils). This may cause registration problems or shorts during manufacturing.

Location: 22.790, 13.230 (in.) Layers: gnd2530.pho, Drill.drl Attributes: NC Tool=5 Net=\$Net00171



Minimum Clearance: Plane to Drill - (DFM Level: CRITICAL)

Clearance = 4.8 (mils), Minimum allowed 7.0 (mils). This may cause registration problems or shorts during manufacturing.

Location: 22.790, 15.430 (in.) Layers: gnd2530.pho, Drill.drl Attributes: NC Tool=5 Net=\$Net00170



Violation #: 6

DFM Error Report (Page: 3) Date: 08/18/2024@15:06:40

Minimum Clearance: Plane to Drill - (DFM Level: CRITICAL)

Clearance = 4.9 (mils), Minimum allowed 7.0 (mils).

This may cause registration problems or shorts during manufacturing.

Location: 22.788, 17.671 (in.) Layers: gnd2530.pho, Drill.drl Attributes: NC Tool=7 Net=\$Net00169



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.


Location: 17.088, 14.324 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.


Location: 17.488, 13.024 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 17.229, 13.088 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 16.615, 14.305 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 16.609, 14.220 (in.) Layers: Sst0126.pho, Sm0128.pho




DFM Error Report (Page: 4) Date: 08/18/2024@15:06:40

Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 16.914, 14.255 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk:
May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 17.415, 14.305 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk:
May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 17.409, 14.220 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 17.714, 14.255 (in.) Layers: Sst0126.pho, Sm0128.pho



Silkscreen over Soldermask - (DFM Level: ELEVATED)

May make electrical testing and SMT soldering more difficult. The silkscreen overlaps solder mask openings. Elevated Risk: May cause contamination of the pads and make electrical testing plus SMT soldering more difficult.

Location: 19.639, 13.674 (in.) Layers: Sst0126.pho, Sm0128.pho



Mask Slivers - (DFM Level: ELEVATED)

Clearance = 5.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.309, 13.910 (in.)

Layer: Sm0128.pho




DFM Error Report (Page: 5) Date: 08/18/2024@15:06:40

Mask Slivers - (DFM Level: ELEVATED)

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.283, 13.910 (in.)

Layer: Sm0128.pho




Mask Slivers - (DFM Level: ELEVATED)

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.257, 13.910 (in.)

Layer: Sm0128.pho



Mask Slivers - (DFM Level: ELEVATED)

Clearance = 5.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.232, 13.910 (in.)

Layer: Sm0128.pho



Violation #: 21

Mask Slivers - (DFM Level: ELEVATED)

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.206, 13.910 (in.)

Layer: Sm0128.pho



Mask Slivers - (DFM Level: ELEVATED)

Clearance = 5.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.181, 13.910 (in.)

Layer: Sm0128.pho



Mask Slivers - (DFM Level: ELEVATED)

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.155, 13.910 (in.)

Layer: Sm0128.pho



Violation #: 24

DFM Error Report (Page: 6) Date: 08/18/2024@15:06:40

Mask Slivers - (DFM Level: ELEVATED)

Violation #: 25

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.129, 13.910 (in.)

Layer: Sm0128.pho




Mask Slivers - (DFM Level: ELEVATED)

Violation #: 26

Clearance = 5.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.104, 13.910 (in.)

Layer: Sm0128.pho




Mask Slivers - (DFM Level: ELEVATED)

Violation #: 27

Clearance = 6.0 (mils), Minimum allowed 8.0 (mils). Areas in the solder mask where the resist is so narrow that it may cause small pieces of the resist to flake off and present soldering problems later. Critical: A board can fail if the resist falls in an area that needs to be soldered later on.

Location: 19.078, 13.910 (in.)

Layer: Sm0128.pho




Missing Mask Clearances - (DFM Level: MEDIUM)

Violation #: 28

May result in a short, as well as reduced corrosion protection.

Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly.

Location: 17.824, 14.228 (in.) Layers: Sm0128.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00000



Missing Mask Clearances - (DFM Level: MEDIUM)

May result in a short, as well as reduced corrosion protection.

Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly.

Location: 17.284, 14.238 (in.) Layers: Sm0128.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00001



Missing Mask Clearances - (DFM Level: MEDIUM)

Violation #: 30

May result in a short, as well as reduced corrosion

Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly.

Location: 16.864, 14.238 (in.) Layers: Sm0128.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00000



DFM Error Report (Page: 7)
Date: 08/18/2024@15:06:40

Missing Mask Clearances - (DFM Level: MEDIUM) Violation #: 31 May result in a short, as well as reduced corrosion protection. Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 16.574, 14.168 (in.) Layers: Sm0128.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00001 Missing Mask Clearances - (DFM Level: MEDIUM) Violation #: 32 May result in a short, as well as reduced corrosion protection. Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 17.824, 14.228 (in.) Layers: Sm0227.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00000 Missing Mask Clearances - (DFM Level: MEDIUM) Violation #: 33 May result in a short, as well as reduced corrosion protection. Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 17.284, 14.238 (in.) Layers: Sm0227.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00001 Missing Mask Clearances - (DFM Level: MEDIUM) Violation #: 34 May result in a short, as well as reduced corrosion protection. Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 16.864, 14.238 (in.) Layers: Sm0227.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00000 Missing Mask Clearances - (DFM Level: MEDIUM) May result in a short, as well as reduced corrosion protection. Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 16.574, 14.168 (in.) Layers: Sm0227.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00001 Missing Mask Clearances - (DFM Level: MEDIUM) Violation #: 36 May result in a short, as well as reduced corrosion Exposes more copper than is necessary, and can result in solder bridges forming accidentally between pins during assembly. Location: 18.744, 13.948 (in.) Layers: Sm0128.pho, Drill.drl Attributes: NC Tool=9 Net=\$Net00001

DFM Error Report (Page: 8)
Date: 08/18/2024@15:06:40



